

Russell Taylors

www.russelltaylors.co.uk

**USER MANUAL
RICE COOKER RC20**

E-WARRANTY




SCAN HERE




Safety Instructions & Precautions

1. This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning the use of this appliance in a safe and responsible way. Cleaning and user maintenance should not be made by children. Keep the appliance and its cord of reach of children.
2. Children must be supervised while using this appliance and not play with the appliance.
3. This appliance can be used by persons with reduced physical, sensor or mental capabilities if they are supervised while using the appliance and understand the hazards involved.
4. This appliance is intended for household use only.
5. The surface of the heating element is subject to residual heat after use.
6. If the supply cord is damaged, it must be replaced by the manufacturer or its service centre.
7. Do not immerse the appliance or its power cord in water or any other liquids.
8. To prevent a fire or electrical shock, do not place the power line and plug in the water or any other liquid.
9. The plug has to be unplugged when cleaning or not using the equipment. The accessories can be cleaned only after the equipment is cooled.

Product Structure



Control Panel Layout



Slow Cook

The cooking time is 45 minutes by default and cannot be adjusted. Once the menu has been selected, the “slow cooking” indicator will remain on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the “end” indicator will be displayed with three beeps heard. The device will now enter the “Keep Warm” mode.

Low Sugar Rice

The default cooking time is 45 minutes and cannot be adjusted. Once the menu has been selected, the “low sugar rice” indicator light remains turned on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the “end” indicator will be displayed with three beeps heard. The maximum amount of rice is 2 cups of rice, and the water should be barely higher than the rice surface (around 5-8mm higher).

Claypot Rice

The cooking time is 50 minutes and cannot be adjusted. Once the menu has been selected, the “Claypot Rice” indicator light remains turned on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the “end” indicator will be displayed with three beeps heard. The device will now enter the “Keep Warm” mode.

Multigrain Rice

The cooking time is 55 minutes and cannot be adjusted. Once the menu has been selected, the “Multigrain Rice” indicator light remains turned on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the “end” indicator will be displayed with three beeps heard. The device will now enter the “Keep Warm” mode.

Porridge

The cooking time is 60 minutes and cannot be adjusted. Once the menu has been selected, the “Porridge” indicator light remains turned on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the

“end” indicator will be displayed with three beeps heard. The device will now enter the “Keep Warm” mode.

Fast Cook

The cooking time is 35 minutes and cannot be adjusted. Once the menu has been selected, the “Quick Cooking” indicator light remains turned on. 10 minutes before the sequence is completed, the 10-minute countdown display will show and once the timer runs out, the “end” indicator will be displayed with three beeps heard. The device will now enter the “Keep Warm” mode

Keep Warm

When a function has finished, the rice cook automatically enters the keep warm mode for 4 minutes. It can be adjusted by pressing the “+/-” keys to adjust the keep warm time between 30 minutes and 24 hours.

To manually set the keep warm function, select the keep warm function and press the “Start/Cancel” key to enter the keep warm mode. The rice cook automatically enters the keep warm mode for 4 minutes. It can be adjusted by pressing the “+/-” keys to adjust the keep warm time between 30 minutes and 24 hours.

Preset

Select the function desired. Once you have selected the function, press the “Preset” button and adjust the timer using the “+/-” buttons between 10 minutes and 24 hours. The rice cooker will enter the “preset” mode after 5 seconds. The final completion time is equal to the function working time and the “preset” time.

Cancel

If you have selected the wrong menu option, you can press the cancel button and the rice cooker will pause. Re-select the correct function and the cooker will begin cooking again.

Cleaning & Maintenance

1. Wash the inner pot with hot water, detergent and a soft sponge. Never use steel wire balls or abrasive material.
2. If the food sticks to the bottom of the pot, soak the pot in warm water before cleaning and then clean it after a few minutes.
3. Use a plastic or wooden spoon.
4. Always clean the middle ring, seal cover and exterior of the rice cooker with a damp cloth.
5. If there is water on the heating disc, wipe it dry with a cloth.

Troubleshooting

Faults	Causes	Solutions
The screen does not light up.	The product is not connected	Check if it is plugged into a power supply
The heating disc does not heat up	Circuit board failure	Contact our customer service team
	Fuse has blown out	
The rice is undercook	The ratio of water and rice is incorrect	Adjust the volume of rice and water.
	The pot is not properly placed in the rice cooker	Rotate the pot left and right to place it correctly
	Circuit Failure	Contact our customer service team
	Sensor Failure	
Overflow	Too much water in the pot	Reduce volume of water