

Russell Taylors

E-WARRANTY




SCAN HERE

www.russelltaylors.co.uk

USER MANUAL PORTABLE BLENDER PB1



Product Details



First Time Usage

1. Press the power button and a blue LED light will flash around the "Start/Stop" button indicating that the blender can be used.
2. The LED light rotates clockwise when the machine is turned on, and the default running time is 20 seconds.
3. If the blender display a flashing red & blue light when pressing the "Start/Stop" button, this means that the safety switch is not detected and the bottle has not been locked in appropriately.
4. If the red light flashes after the "Start/Stop" button is pressed, this indicates that there is an object stuck under the blade and it has entered the overload protection mode.


Instructions On Proper Use

Charging Method :

- Connect your charging brick into a power source.
- Insert the Type-C cable into the USB charging port.
- A red LED light will switch on to notify that the battery is now charging.


Power Indicator :

- While charging, the red LED lights move clockwise from low to high power. After charging is completed, a blue LED light will be displayed.



Startup :

- Hold the Power Switch and the blue LED light will switch on.
- The blender has now entered the standby mode.
- Press the Start/Stop button to switch on the blender, pressing the same button again to turn it off.



Blending Fruits & Vegetables :

- Cut the fruits & vegetables into small pieces (2cm pieces)
- Place the cut fruits and vegetables into the cup. The fruits and vegetables should not be more than 1/2 of the cups capacity)
- Add an appropriate amount of water or milk, ensuring that the liquid is **at least 3 fingers length away from the cup mouth.**
- Switch on the blender and press the Start/Stop button to begin blending, pressing the same button to stop blending based on your requirements.

Cleaning & Maintenance

- Before cleaning, make sure the blender is switched off and the blades have stopped moving.
- The main base can be cleaned by wiping it with a dry or damp cloth. Never use sharp objects or corrosive liquid solvents to clean the products.
- Clean the blades with a small brush.
- Never touch the blades with your fingers to avoid injury.

Safety Precautions

- It is forbidden to switch on the blender without the lid or when the base is not tightened firmly.
- Do not open the blender when it's turned on for personal safety.
- Never touch the blades with your bare fingers when cleaning.
- Do not use the blender continuously when the base is at a high temperature. Let it cool before running again.
- Do not use when any water leakage is found. The product will need to be sent back to the Russell Taylors service centre for repairs.
- The battery must be charged every 3 months or the battery will be permanently damaged. DO not use it continuously for more than 1 minute. Allow the blender to rest in 1 minute intervals after each use.
- Do not place the blender within reach of children.
- Do not allow children to use the blender alone without supervision.