

Russell Taylors

E-WARRANTY



SCAN HERE

www.russelltaylors.co.uk

DUST MITE VACUUM


USER MANUAL

VM-10



This product is covered by a 2-year warranty against manufacturing defects. For all warranty claims, please email malaysia@russelltaylors.co.uk and include your order ID number as proof of purchase. You are entitled to one (1) warranty claim during the warranty period.


PRODUCT INFORMATION




HOW IT WORKS

1. Connect the plug of the cord to a power source, then press the power button to start.
2. Place the machine on the object to clean. Ensure both wheels on the machine are pressed in. A blue light on the bod of the machine will flash on to indicate that the UV light is activated. (This also indicates that the UV has been shielded from the user and is safe for operation. Proceed to clean as desired.)
3. Store in a safe and dry location upon completion.


1. Starting the machine:
Connect the power plug and switch it on. The vacuum is turned on by pressing down on the switch button. Press it down again to turn it off.




2. When cleaning the mattress, gently push the machine downwards, keeping it parallel with the surface. Ensure the machine is constantly flat.



3. For carpet use, put the machine flat on the surface and move it according to the image below



4. When cleaning a pillow or cushion, move the machine back and forth as shown in image below




WARNING

Incorrect operation may lead to body injury or even death. And it also may cause damage of property. To reduce fire and electric shock or other injuries, please pay attention to following points:

1. Before each use, check your main power supply voltage for compatibility with the product. Refer to product voltage on the product rating label



2. Do not use machine outdoors or on wet surface



3. Before each use, please ensure the dust cup is correctly installed on the machine. If the installation is not correct it may cause damage to the machine or impact its working efficiency. Please dry dust cup before installation.

4. Do not block the inlet and outlet vents of the machine, do not operate machine if vents are blocked. Ensure vents are clear of any foreign dirt/debris that may hinder airflow

5. When moving the machine, please shut off the power. Unplug the machine when it is not in use.

6. Do not use or store machine near the following objects: stove or other similar heating equipment, inflammable gas, and/or other inflammable materials.

7. This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety


8. Do not run multiple electrical appliances on extension cords



9. If the metal part of the plug stick dust or water, please clean it by towel. Don't run machine or connect to power source when plug is wet.



10. When in use, do not lift or move machine by power cord. Do not place power cord under doors, sharp objects or corners. Don't run machine when power cord is pressed obstructed



11. Do not use machine suction for substances with smoke, sharp edges, and liquids (i.e.: cigarettes, knives, water).



12. When inserting or disconnecting plug, do not touch the metal pins. Do not handle plug with wet hands



13. Before each clean, please ensure plug is disconnected. Do not clean machine with water, alcohol, and other cleaning agents.



MAINTENANCE AND CLEANING

1. Dust and stains on the light tube will impact UV intensity and efficiency in cleaning. Wipe the light tube regularly to avoid the decline of the penetrating power and light intensity.
2. Do not touch glass of the light tube – stains will impact sterilizing tube.
3. Clean HEPA filter regularly (ensure filter is completely dry before re-use)
4. Do not disassemble machine to clean light tube – contact our service center

Cleaning the machine

Shut down the machine and pull out the power plug, twist the cover of the dust cup counter-clockwise (upwards) to remove dust cup. Remove the HEPA filter to clean as required. The filter element and strainer mesh can be washed by water, and put back to the dust cup after they are completely dry.

1. Upkeep and maintenance must be performed after the power plug has been disconnected.
2. Ensure dust cup is emptied regularly to maintain machine efficiency.
3. Do not clean surface of vacuum cleaner using gas or other oily matter. The user should clean it with a soft cloth or neutral liquid detergent. Never allow water to enter into the vacuum cleaner.

4. Pull out the power cord, separate machine and power cord and store in cold, dry place.

5. Do not place heavy objects on the machine.

Russell Taylors

www.russelltaylors.co.uk

